



# ELECTRICAL

## Section 2A – Ignition

### Table of Contents

**2**  
**A**

Specifications .....	2A-1	Direct Injectors .....	2A-21
Special Tools .....	2A-2	Fuel Injectors .....	2A-21
Coil Plate .....	2A-4	Disconnecting Harness Connectors from Ignition Coils and/or Injectors .....	2A-22
Solenoid Plate Model .....	2A-6	Troubleshooting .....	2A-22
Solenoid Plate .....	2A-7	Troubleshooting Without Digital Diagnostic Terminal .....	2A-22
Theory of Operation .....	2A-9	Troubleshooting With the Digital Diagnostic Terminal .....	2A-23
Ignition Component Description .....	2A-10	Notes: .....	2A-24
Fuses .....	2A-10	DDT Functions – Optimax Models Software Version 1.0 (P/N 880118) .....	2A-25
Electronic Control Module (ECM) .....	2A-11	Ignition Components Removal and Installation .....	2A-30
Flywheel .....	2A-11	Flywheel Cover Removal and Installation .....	2A-30
Ignition Coils .....	2A-12	Electronic Control Module (ECM) .....	2A-31
Coil Driver .....	2A-13	Ignition Module (Coil) .....	2A-32
Crank Position Sensor .....	2A-14	Crank Position Sensor .....	2A-33
Throttle Position Sensor (TPS) .....	2A-14	Throttle Position Sensor (TPS) .....	2A-34
Throttle Position Sensor (TPS) Troubleshooting .....	2A-15		
Charging System Alternator .....	2A-16		
Temperature Sensor .....	2A-17		
Manifold Absolute Pressure (MAP) Sensor .....	2A-20		
Air Temperature Sensor .....	2A-20		


### Specifications

<b>IGNITION SYSTEM</b>	<b>Type</b> <b>Spark Plug Type</b> <b>Spark Plug Gap</b> <b>Maximum Timing</b> <b>Idle Timing</b> <b>Throttle Position Sensor</b> @ Idle @ WOT <b>Crank Position Sensor</b>	Digital Inductive NGK PZFR5F-11 0.043 in. (1.1 mm) Not Adjustable; Controlled by ECM Not Adjustable; Controlled by ECM  0.4 – 1.3 VDC 4.0 – 4.7 VDC Not Adjustable
------------------------	---	--




# Special Tools


1. Digital Diagnostic Terminal (DDT) 91-823686A2




2. Software Cartridge 91-880118A2



3. DDT Reference Manual 90-881204-1




4. Adaptor Harness 84-822560A5






5. DMT 2000A Digital Tachometer Multimeter 91-854009A3




6. Spark Gap Tester 91-850439T1






# Coil Plate



 6 Dielectric Grease

 25 Liquid Neoprene




# Coil Plate

REF. NO.	QTY.	DESCRIPTION	TORQUE		
			lb-in	lb-ft	Nm
1	1	COIL MOUNTING PLATE			
2	4	BUSHING			
3	4	GROMMET			
4	4	WASHER			
5	2	WASHER			
6	4	SCREW (M8 x 35)		19.6	26.6
7	2	CABLE ASSEMBLY Ground			
8	4	WASHER			
9	2	SCREW (M6 x 10)	60		6.8
10	6	IGNITION COIL			
11	3	DUAL COIL DRIVER			
12	12	SCREW (M6 x 30)	60		6.8
13	2	SCREW (M6 x 14) Ground Cables	15		1.7
14	6	HIGH TENSION CABLE			
15	6	SPARK PLUG PZFR5F-11		20.4	27.7
16	2	J CLIP			
17	1	TUBING (18 IN.)			
18	1	CLIP			
19	1	FITTING			
20	1	SENSOR Block Pressure			
21	1	FITTING To Back Of Block-Lower Port Side			



# Solenoid Plate Model



**NOTE:** Coat all eyelet wiring terminals with #25 GACO N700.

**NOTE:** Coat all multi-pin electrical connections (except power trim relay connections) with #6DC-4.




# Solenoid Plate

REF. NO.	QTY.	DESCRIPTION	TORQUE		
			lb-in	lb-ft	Nm
1	1	HARNESS ASSEMBLY Engine			
2	4	FUSE-Mini (Yellow-20 AMP)			
2	1	FUSE-Mini (Blue-15 AMP)			
3	1	COVER-Fuse			
4	AR	CONDUIT (.035 ID X 3.00 Feet) Cut As Required			
4	AR	CONDUIT (.050 ID X 3.00 Feet) Cut As Required			
4	AR	CONDUIT (.062 ID X 3.00 Feet) Cut As Required			
4	AR	CONDUIT (1.00 ID X 3.00 Feet) Cut As Required			
5	1	COVER-Fuse			
6	1	FUSE (Tan-5 AMP)			
7	2	PLUG-Male			
8	1	CAP-Female			
9	1	CONNECTOR ASSEMBLY			
10	AR	CABLE TIE (8 IN.)			
11	1	PLATE-Relay/Solenoid Mount			
12	3	SCREW (M6 x 12)	100		11.3
13	1	CLIP			
14	1	SOLENOID ASSEMBLY			
15	2	GROMMET			
16	2	BUSHING			
17	1	CLIP			
18	2	SCREW (M6 x 14) Ground Screws	60		6.8
19	1	RELAY ASSEMBLY			
20	1	BRACKET			
21	1	BUSHING			
22	1	GROMMET			
23	1	DECAL			
24	3	SCREW (M6 x 25)	60		6.8
25	1	CABLE ASSEMBLY			
26	2	NUT (10-32) Brass	40		4.5
27	1	CAP NUT			
28	1	HARNESS ASSEMBLY-Fuse (100 AMP)(34.5 IN.)			
29	1	CABLE ASSEMBLY Starter			
30	2	LOCKWASHER			
31	2	NUT (5/16-18)	60		6.8
32	1	BOOT-Insulator (Red)			
33	1	WASHER			
34	1	BOOT-Insulator (Yellow)			
35	3	BUSHING			
36	3	GROMMET			
37	1	ECU			



# Solenoid Plate Model



**NOTE:** Coat all eyelet wiring terminals with #25 GACO N700.

**NOTE:** Coat all multi-pin electrical connections (except power trim relay connections) with #6DC-4.





## Solenoid Plate

REF. NO.	QTY.	DESCRIPTION	TORQUE		
			lb-in	lb-ft	Nm
38	3	WASHER			
39	3	SCREW (M6 x 25)	100		11.3
40	1	BRACKET			
41	1	CLIP			
42	2	SCREW (M6 x 14)	100		11.3
43	1	CLIP-Conduit Support			

### Theory of Operation

When the ignition key is turned to the RUN position, battery voltage is applied to the main relay through the PURPLE wire. When the Electronic Control Module (ECM) receives a signal from the Crank Position Sensor, the main relay ground circuit is completed through the ECM. The main relay is then closed and D.C. current from the battery or charging system is transferred through the main relay 20 ampere fuse to the positive terminal of all 6 ignition coil primary windings. The negative terminal of the coil primary is connected to engine ground through the Dual Coil Driver which is triggered by the ECM. At this time, when this circuit is closed, a magnetic field is allowed to be built up in the ignition coil. The Crank Position Sensor senses the location of the 54 teeth on the flywheel and supplies a trigger signal to the ECM. ECM provides a signal to the dual coil driver prior to cylinder firing. The Crank Position Signal the ECM receives also determines when the trigger signal is removed from the Coil Driver thus turning off the driver and opening the ground circuit of the coil primary. The magnetic field in the ignition coil primary will then collapse cutting across the coil secondary winding creating a high voltage charge (50,000 volts) that is sent to the spark plug.




# Ignition Component Description

## Fuses

The electrical wiring circuits on the outboard are protected from overload by fuses in the wiring. If a fuse is blown, try to locate and correct the cause of the overload. If the cause is not found, the fuse may blow again.

1. Open the fuse holder and look at the silver colored band inside the fuse. If band is broken, replace the fuse. Replace fuse with a new fuse with the same rating.
2. The fuses and circuits are identified as follows:



- a** - Smart Craft Data Bus Circuit – SFE 15 AMP Fuse.
- b** - Accessories – SFE 20 AMP Fuse.
- c** - Ignition Coil Circuit – SFE 20 AMP Fuse.
- d** - Electric Fuel Pump/ECM Driver Power/Oil Pump Circuit – SFE 20 AMP Fuse.
- e** - Fuel Lift Pump – SFE 5 AMP Fuse.




## Electronic Control Module (ECM)

The ECM requires 8 VDC minimum to operate. If the ECM should fail, the engine will stop running.

The inputs to the ECM can be monitored and tested by the Digital Diagnostic Terminal 91-823686A2 using adaptor harness 84-822560A5.

The ECM performs the following functions:


- Calculates the precise fuel and ignition timing requirements based on engine speed, throttle position, manifold pressure and coolant temperature.
- Controls fuel injectors for each cylinder, direct injectors for each cylinder and ignition for each cylinder.
- Controls all alarm horn functions.
- Supplies tachometer signal to gauge.
- Controls RPM limit function.
- Records engine running information.



**a** - Electronic Control Module (ECM)

## Flywheel

54 teeth under the flywheel ring gear provide engine rpm and crankshaft position information to the ECM through the crank position sensor.




**a** - Flywheel  
**b** - Crank Position Sensor



## Ignition Coils

Inductive type ignition coils are used on the DFI engines. 12 volt DC is supplied to the coils at all times from the boat battery. For a predetermined length of time (dwell), the primary circuit of the coil is completed by closing the electrical circuit within the coil driver. When the coil driver circuit opens, the primary field of the coil collapses inducing high voltage in the secondary windings which produces up to 50000 volts at the spark plugs.



00029

**a** - Ignition Coils – 3 coils are mounted behind 3 visible coils

### Ignition Coil Ohm Test

Connect meter leads between primary terminal (GREEN/Striped) and (RED/YELLOW) terminal pin.	0.38 - 0.78 $\Omega$
Connect meter leads between spark plug wire/high voltage tower and ground terminal pin.	8.1 - 8.9 k $\Omega$




# Coil Driver

The ECM sends a 5 VDC pulse to the coil driver mounted on each ignition coil. Which coil driver receives this pulse is determined by the ECM receiving a signal from the crank position sensor.

When the coil driver receives its ECM pulse (signal), it closes its circuit which allows the primary side of the ignition coil to build up energy which it initially receives from the boat battery.


When the ECM pulse (signal) to the coil driver drops below 1.3 volts, the coil driver opens its circuit which causes the primary field of the ignition coil to collapse. This field collapse induces a voltage buildup in the secondary winding of the ignition coil resulting in a potential voltage of up to 50000 volts at the spark plug.



- a** - Coil Driver
- b** - 4 Pin Connector

- c** - 2 Pin Connector

## Coil Driver Ohm Test



58418


4 Pin Connector – Connect meter leads between RED/YELLOW and BLACK male pins.	85 k $\Omega$ $\pm$ 10%
4 Pin Connector – Connect meter leads between BLACK male pin and each GREEN STRIPED male pin.	10 k $\Omega$ $\pm$ 10%
Connect meter leads between BLACK male pin on 4 pin connector and each GREEN STRIPED male pin on the 2 pin connector.	OPEN – No Continuity



## Crank Position Sensor

Senses 54 teeth located on flywheel under ring gear.

Supplies the ECM with crank position information and engine speed. If sensor should fail, the engine will stop running.




**a** - Crank Position Sensor

58323

## Throttle Position Sensor (TPS)

The TPS transmits throttle angle information to the ECM which varies the injector pulse width accordingly. Should the sensor fail, the warning horn will sound. RPM will be reduced by the ECM. TPS settings are not adjustable. TPS settings can be monitored with the Digital Diagnostic Terminal through the ECM. Voltage change should be smooth from idle to wide open throttle. If voltage change is erratic, TPS is defective.



**a** - Throttle Position Sensor (TPS)

59414

Throttle Position Sensor Specifications	
Idle	0.4 – 1.3 VDC
Wide Open Throttle	4.0 – 4.7 VDC



## Throttle Position Sensor (TPS) Troubleshooting


If the throttle position sensor is out of the intended operating range when the engine is started, the Electronic Control Module (ECM) will sense that the Throttle Position Sensor (TPS) has failed. The warning horn will sound, DDT will indicate failed TPS and the engine will go into RPM reduction. When the engine is started, the throttle arm on the engine must be against the throttle stop screw. Do not move throttle lever forward.

- Check throttle cable adjustment. The throttle stop screw on the throttle arm must be against the throttle stop on the cylinder block when the engine is started. Pre-load the throttle cable barrel 1 or 2 turns if necessary.
- Verify driver is not pushing on throttle (if foot throttle is used) or advancing the throttle only on the control box.
- Check throttle cam to roller adjustment. If the roller is not down in the pocket/valley area on the cam, there is a tendency for the roller to ride up or down on the cam which causes the TPS link arm to push/pull on the TPS lever resulting changing values.



## Charging System Alternator

Battery charging system is contained within the belt driven alternator, including the regulator. At cranking speeds, electrical power for the engine is provided by the boat battery – minimum recommended size is 750 CCA, 1,000 MCA, cold cranking amperes or 105 (Minimum) Ampere Hours. Above 900 RPM, all electrical power is provided by the alternator. Should engine rpm drop below 900 RPM, the alternator is not capable of providing sufficient output and the battery becomes the primary source of electrical power. Alternator output (when hot) to the battery @ 2000 RPM is approximately 33 - 38 amperes.



**a** - Alternator







## Temperature Sensor

Three (3) temperature sensors are used to provide temperature information to the ECM. One sensor is mounted in each cylinder head and one sensor is mounted in the air compressor cylinder head.

The ECM uses this information to increase injector pulse width for cold starts and to retard timing in the event of an over-heat condition. The ECM will also use the information to increase idle speed to regulate cooling on hot and cold starts.



00029



- a** - Cylinder Temperature Sensor (STARBOARD)
- b** - Cylinder Temperature Sensor (PORT)
- c** - Air Compressor Temperature Sensor



## AIR COMPRESSOR TEMPERATURE SENSOR TEST

Between TAN/BLACK and each TAN/BLACK wire.	No Continuity
Between each lead and ground	No Continuity

Temperature Sensor Specifications		
Fahrenheit	Centigrade	OHMS ( $\pm 10\%$ )
-22	-30	18230
-13	-25	13420
-4	-20	9966
5	-15	7465
14	-10	5636
23	-5	4288
32	0	3287
41	5	2551
50	10	1996
59	15	1574
68	20	1250
77	25	1000
86	30	805
95	35	653
104	40	532
113	45	437
122	50	360
131	55	299
140	60	249
149	65	209
158	70	176
167	75	148
176	80	126
185	85	107



## PORT AND STARBOARD CYLINDER TEMPERATURE SENSORS AIR TEMPERATURE SENSOR

An ohms test of the temperature sensors would be as follows:


Disconnect temperature sensor harness and check continuity with digital or analog ohm-meter test leads between both connector pins. With engine at temperature (F°) indicated, ohm readings should be as indicated  $\pm 10\%$ . There should be no continuity between each connector pin and ground.

Temperature Sensor Specifications		
Fahrenheit	Centigrade	OHMS
257	125	340
248	120	390
239	115	450
230	110	517
221	105	592
212	100	680
203	95	787
194	90	915
185	85	1070
176	80	1255
167	75	1480
158	70	1752
149	65	2083
140	60	2488
131	55	2986
122	50	3603
113	45	4370
104	40	5327
95	35	6530
86	30	8056
77	25	10000
68	20	12493
59	15	15714
50	10	19903
41	5	25396
32	0	32654
14	-10	55319
5	-15	72940



## Manifold Absolute Pressure (MAP) Sensor

The MAP sensor is mounted on top of the air plenum. The ECM regulates fuel flow, in part, based on manifold absolute pressure.




57793

**a** - MAP Sensor

## Air Temperature Sensor

The air temperature sensor is mounted on top of the air plenum. The ECM regulates fuel flow, in part, based on manifold air temperature. As air temperature increases, the ECM decreases fuel flow.




57793

**a** - Air Temperature Sensor




## Direct Injectors

6 direct injectors (1 per cylinder) are used to inject a fuel/air mix into cylinders. Injectors are mounted between fuel rails and cylinder heads.



57986



57985

### Direct Injector Ohm Test (Injector Lead Disconnected)

Connect meter leads between each injector terminal pin.


1 - 1.6  $\Omega$ 

Connect 1 meter lead to either injector pin while touching the other meter lead to the injector metal case.

No continuity

## Fuel Injectors

6 fuel injectors (1 per cylinder) are used to provide fuel from the fuel rail to the direct injectors. The fuel injectors are mounted in the fuel rail.



00029


### Fuel Injector Ohm Test (Injector Lead Disconnected)

Connect meter leads between each injector terminal pin.

1.7 - 1.9  $\Omega$



## Disconnecting Harness Connectors from Ignition Coils and/or Injectors



**a** - Wire Clip (push center down to remove)

### Troubleshooting

The ECM is designed such that if a sensor fails, the ECM will compensate so that the engine does not go into an over-rich condition.

Disconnecting a sensor for troubleshooting purposes may have no noticeable effect.

## Troubleshooting Without Digital Diagnostic Terminal

Troubleshooting without the DDT is limited to checking resistance on some of the sensors.

Typical failures usually do not involve the ECM. Connectors, set-up, and mechanical wear are most likely at fault.

- Verify spark plug wires are securely installed (pushed in) into the coil tower.
- The engine may not run or may not run above idle with the wrong spark plugs installed.
- Swap ignition coils to see if the problem follows the coil or stays with the particular cylinder.

**NOTE:** ECMs are capable of performing a cylinder misfire test to isolate problem cylinders. Once a suspect cylinder is located, an output load test on the ignition coil, fuel injector and direct injector may be initiated through use of the DDT.


- Any sensor or connection can be disconnected and reconnected while the engine is operating without damaging the ECM. Disconnecting the crank position sensor will stop the engine.

**IMPORTANT:** Any sensor that is disconnected while the engine is running will be recorded as a Fault in the ECM Fault History. Use the DDT to view and clear the fault history when troubleshooting/repair is completed.

- If all cylinders exhibit similar symptoms, the problem is with a sensor or harness input to the ECM.
- If problem is speed related or intermittent, it is probably connector or contact related. Inspect connectors for corrosion, loose wires or loose pins. Secure connector seating; use dielectric compound.
- Inspect the harness for obvious damage: pinched wires, chaffing.
- Secure grounds and all connections involving ring terminals (coat with Liquid Neoprene).
- Check fuel pump connections and fuel pump pressure.
- Check air compressor pressure.



# Troubleshooting With the Digital Diagnostic Terminal



- a** - Digital Diagnostic Terminal (91-823686A2)
- b** - Software Cartridge (91-880118A2)
- c** - DDT Reference Manual (90-881204-1)
- d** - Adapter Harness (84-822560A5)

The Quicksilver Digital Diagnostic Terminal (DDT) has been developed specifically to help technicians diagnose and repair Mercury Marine 2 and 4 cycle engines.

Attach the diagnostic cable to the ECM diagnostic connector and plug in the software cartridge. You will be able to monitor sensors and ECM data values including status switches.

The ECM program can help diagnose intermittent engine problems. It will record the state of the engine sensors and switches for a period of time and then can be played back to review the recorded information.

Refer to the Digital Diagnostic Terminal Reference Manual for complete diagnostic procedures.




# Notes:





# DDT Functions – Optimax Models Software Version 1.0 (P/N 880118)





DFI Troubleshooting Guide		
Symptom	Cause	Action
1. Engine cranks but won't start	<b>1.0</b> Lanyard stop switch in wrong position.	Reset lanyard stop switch.
	<b>1.1</b> Weak battery or bad starter motor, battery voltage drops below 8 volts while cranking (ECM cuts out below 8 volts) (Fuel pump requires 9 volts).	Replace/charge battery. Inspect condition of starter motor. Check condition of battery terminals and cables.
	<b>1.2</b> Low air pressure in rail (less than 70 psi at cranking)	Inspect air system for leaks. Inspect air filter for plugging (air pressure measured on port rail). Inspect air compressor reed valves if necessary.
	<b>1.3</b> No fuel	Key-on engine to verify that fuel pump runs for 2 seconds and then turn off. Measure fuel pressure (valve on starboard rail). Fuel pressure should be $10 \pm 1$ psi greater than the air pressure.
	<b>1.4</b> Low fuel pressure	Check fuel pressure from low pressure electric fuel pump (6–10 psi). Check for fuel leaks. If fuel pressure leaks down faster than air pressure, seals on fuel pump may be leaking. Check air system pressure, see <b>1.2</b> .
	<b>1.5</b> Flywheel misaligned during installation	Remove flywheel and inspect.
	<b>1.6</b> Blown fuse	Replace fuse. Inspect engine harness and electrical components.
	<b>1.7</b> Main Power Relay not functioning	Listen for relay to “click” when the key switch is turned on.
<b>1.8</b> Spark Plugs	Remove fuel pump fuse. Unplug all direct injector connectors. Remove spark plugs from each cylinder. Connect spark plug leads to Spark Gap Tester 91-850439T. Crank engine or use DDT output load test for each ignition coil and observe spark. If no spark is present, replace appropriate ignition coil. If spark is present, replace spark plugs.	



DFI Troubleshooting Guide (continued)		
Symptom	Cause	Action
1. Engine cranks but will not start (continued)	<p><b>1.9</b> ECM not functioning</p> <p><b>1.9A</b> Crank Position Sensor not functioning</p>	<p>Injection System: Listen for injector “ticking” when cranking or connect spare injector to each respective harness. Ticking should start after 2 cranking revolutions.</p> <p>Ignition System: – Check for proper operation by using Inductive Timing Light 91-99379. – Check battery voltage (RED/YEL Lead) @ ignition coils. – Check for blown fuse (C15). – Check battery voltage to fuse from main power relay (PURPLE Lead). – Check for shorted stop wire (BLK/YEL). – Check crank position sensor setting [0.025 in. – 0.040 in. (0.64 mm – 1.02 mm)] from flywheel or for defective crank position sensor. – Defective ECM.</p> <p>Power Supply: Clean and inspect remote control male and female harness connectors.</p> <p>– Sensor faulty. – Bad connection – Air gap incorrect</p>
2. Engine cranks, starts and stalls	<p><b>2.0</b> Low air pressure in rail</p> <p><b>2.1</b> Low fuel pressure in rail</p> <p><b>2.2</b> Abnormally high friction in engine</p> <p><b>2.3</b> Air in fuel system/lines</p> <p><b>2.4</b> TPS malfunction</p> <p><b>2.5</b> Remote control to engine harness connection is poor</p>	<p>See <b>1.2</b></p> <p>See <b>1.2</b> and <b>1.3</b></p> <p>Check for scuffed piston or other sources of high friction.</p> <p>See <b>1.3</b> Crank and start engine several times to purge.</p> <p>Check motion of throttle arm. Stop nuts should contact block at idle and WOT. Check TPS set-up. Must connect DDT with adapter harness (84-822560A5) to ECM.</p> <p>Clean and inspect male and female connectors.</p>



<b>DFI Troubleshooting Guide (continued)</b>		
<b>Symptom</b>	<b>Cause</b>	<b>Action</b>
<b>3.</b> Engine idle is rough	<b>3.1</b> Low air pressure in rail (less than 79 ± 2 psi while running) <b>3.2</b> Fouled spark plug  <b>3.3</b> Failed direct injector <b>3.4</b> Failed fuel injector <b>3.5</b> Bad coil/weak spark <b>3.6</b> Bad dual coil driver <b>3.7</b> Flywheel misaligned during installation	See <b>1.2</b>  Replace spark plug: –If carbon bridges electrode gap or if it is completely black. –If it is not firing and is wet with fuel. <i>Note: If spark plug is grey or completely black with aluminum specs, this indicates a scuffed piston.</i>  Refer to ohm test. Refer to ohm test. Refer to ohm test. Replace dual coil driver. Remove flywheel and inspect.
<b>4.</b> Engine idles fast (rpm >1300) or surges	<b>4.1</b> Broken fuel pressure regulator or tracker diaphragm  <b>4.2</b> Fuel leak  <b>4.3</b> Tracker Valve spring missing <b>4.4</b> Improper set-up <b>4.5</b> TPS malfunction	Measure fuel pressure. Remove and inspect diaphragms (a special tool is required for assembly).  Check for fuel entering induction manifold or air compressor inlet. Vapor Separator flooding over.  Inspect tracker valve for proper assembly.  Check throttle cable & cam roller adjustment.  See <b>2.4</b>
<b>5.</b> Engine runs rough below 3000 rpm	<b>5.1</b> Fouled spark plug  <b>5.2</b> Low air pressure in rail <b>5.3</b> Throttle misadjusted  <b>5.4</b> Bad coil/weak spark <b>5.5</b> Bad dual coil driver <b>5.6</b> TPS malfunction	See <b>3.2</b>  See <b>1.2</b> Check throttle cam setup on induction manifold. Inspect linkage and roller. If throttle plate stop screws have been tampered with, contact Mercury Marine Service Department for correct adjustment procedures.  See <b>3.5</b> Replace dual coil driver See <b>2.4</b>
<b>6.</b> Engine runs rough above 3000 rpm	<b>6.1</b> Fouled spark plug  <b>6.2</b> Speed Reduction  <b>6.3</b> Low air pressure in rails <b>6.4</b> TPS malfunction	See <b>3.2</b>  See <b>7</b>  See <b>1.2</b> See <b>2.4</b>




DFI Troubleshooting Guide (continued)		
Symptom	Cause	Action
7. Speed Reduction (RPM reduced)	7.1 Low battery voltage ECM requires 8 volts minimum Fuel Pump requires 9 volts	Check battery and/or alternator. Check electrical connections.
	7.2 Overheat condition (engine and/or air compressor)	Check water pump impeller/cooling system.
	7.3 Oil pump electrical failure	Check electrical connection.
	7.4 TPS failure If TPS and MAP Sensor fails, rpm is reduced to idle	Check electrical connections.
8. Engine RPM reduced to idle only	8.1 TPS and MAP Sensor failed	See 2.4
	8.2 Battery voltage below 9.5 volts	Use DDT to monitor system
9. Loss of spark on 1 cylinder	9.1 Loose wire or pin in connectors between ECM and coil primary.	Check connectors.
	9.2 Faulty ignition coil.	Replace coil.
	9.3 Faulty dual coil driver	Replace dual coil driver
	9.4 Faulty spark plug.	Replace spark plug.
	9.5 Faulty spark plug wire	Replace spark plug wire.

## Ignition Components Removal and Installation

### Flywheel Cover Removal and Installation

#### REMOVAL

Remove flywheel cover by lifting off.






## INSTALLATION

Install flywheel cover as follows:

- Place cover onto the air attenuator mounting pins.
- Push rear of the cover down onto the rear pins.





57836

## Electronic Control Module (ECM)

### REMOVAL

- Disconnect ECM harness connectors (3).
- Remove 3 bolts securing ECM.



- a** - Electronic Control Module
- b** - Screw [Torque to 100 lb in. (11.5 Nm)]
- c** - Bracket
- d** - Screw [Torque to 70 lb in. (8.0 Nm)]
- e** - Bushing
- f** - Grommet

### INSTALLATION



- Secure ECM to powerhead with 3 bolts.
- Reconnect harness connectors.



# Ignition Module (Coil)

## REMOVAL

1. Disconnect coil harness and spark plug lead.
2. Loosen the electrical mounting plate to gain access to the rear locknuts.
3. Remove module attaching bolts.



00029

- a** - Electrical Mounting Plate
- b** - Bushing
- c** - Rubber Grommet
- d** - Washer
- e** - Bolts (4) – Torque to 20 lb. ft. (27 Nm).
- f** - Screw [Torque to 60 lb. in. (7 Nm)
- g** - Ignition Coils (6)
- h** - Screw [Torque to 60 lb. in. (7 Nm)
- i** - Dual Coil Driver (3)
- j** - Spark Plug
- k** - Spark Plug Boot
- l** - Spark Plug Lead
- m** - Ground Strap




## INSTALLATION

1. Fasten coils to electrical mounting plate as shown.
2. Reinstall electrical mounting plate.
3. Reconnect spark plug lead and coil harness.


## Crank Position Sensor

### REMOVAL

1. Disconnect harness.
2. Remove screws securing sensor to engine.



58323



58613

- a** - Crank Position Sensor  
**b** - Screws – Torque to 45 lb. in (5.0 Nm)

### INSTALLATION

1. Fasten sensor to engine with screws. Torque screws to 45 lb. in. (5.0 Nm).
2. Reconnect sensor harness.






# Throttle Position Sensor (TPS)

## REMOVAL



3. Disconnect TPS connector.
4. Remove 3 screws securing TPS and remove TPS.



- a** - TPS Connector
- b** - Screws
- c** - TPS Link Arm – Disconnect

## INSTALLATION

1. Fasten sensor and bracket to engine as shown.
2. Reconnect wiring harness.



- a** - Bracket
- b** - Sensor
- c** - Screw (3) – Torque to 20 lb. in (2.5 Nm).
- d** - TPS Cover

- e** - Throttle Link
- f** - TPS Lever
- g** - Screw [Torque to 70 lb. in. (8.0 Nm)]
- h** - Bushing (2)
- i** - Grommet
- j** - Clip
- k** - Washer